


Selfie Stick

Selfie Stick L16



User Manual



How to use

- 1. Switch on and off:** Dial the key up to turn on the power; dial the key down to turn off the power;
- 2. Wireless pairing:** The indicator light flashes quickly for 4s to enter the pairing state, the pairing status indicator flashes, use the mobile phone to search for **"Selfie"** to match, and the indicator light will turn off after the pairing is successful;
- 3. Take photos:** When the selfie device is connected to the mobile phone, press the photo button and the indicator will blink.
- 4. Unpaired:** After starting up, it will automatically shut down for 5 mins without operation in unpaired connection state (if you need to turn on the switch again).
- 5. Paired:** When the Selfie is connected to the mobile phone, the indicator light will be off after pairing and connection, and it will go to sleep without any operation for 10 mins;
- 6. Automatic connection:** After powering on, after waking up from sleep, if it has been connected with the paired mobile phone, it will be connected directly and automatically.

Key Function

Use after taking out the selfie and connecting the phone.

Power key 



Power on



Power off




Photo key

click:

Take pictures/video


Use of the Balance Bar

The balance handle can be rotated 360° horizontally, and the mechanical balance of video shooting effectively supports anti-shake shooting.




Upgrade the tripod

Upgraded tripod for enhanced stability.



Widely compatible

1/4" interface compatible with sport camera,
digital camera, ring light;
The phone holder can be used with twins fill lights.



Left picture:
the installation of
the accessory
process.



Specification

- Main Materials : ABS+Aluminum alloy
- Mount Holder : 65-100mm
- Folded Length : 336mm
- Extended Length : 1530mm
- Product Size : 336x75x37.5 mm
- Product Weight : 373g
- Battery : CR1632(replaceable)

(Batteries must not be exposed to sunlight, fire or similar excessive heat)

REMIND

The selfie stick is compatible with Android4.4 and above & iOS 5.1and above.

(Android device: If you change your volumekey function on the camera, be sure to change it to the default value. Or take a picture and let the selfie stick to work normally)

Thank you for your support!

FC CE  RoHS 